

We suggest that you wear the pack with two parallel straps. Connect your straps wherever they feel good. Most of us join one strap at points B & F and the other at C and G. Your size and shape might cause you to prefer connections at A & E and D & H or other combinations. Feel free to mix and match. Adjust the length of the straps for comfort.



Occasionally folks prefer to carry their packs on one shoulder—especially for short distances around school or office. Old fashioned backpacks can cause back, neck and shoulder injury when carried on one shoulder. With this pack you can adjust to carry weight on one shoulder and the pack will center in the middle of your spine. If you're right-shouldered simply remove one strap and snap the second from upper right to lower left (as you face the back). Pick the position that feels comfortable. Most of us prefer D & E. If you're left shouldered, simply angle your strap from upper left to lower right (A to H).

Our backpack allows you to convert your pack to a mail pouch. Simply join two PandoPack straps to create a single long one. Then snap the ends into the appropriate mates on the sides of the pack (I & J). Wear on either shoulder or, better yet, place the long strap over your head so that the pack rests on your hip. Adjust straps to your size. Note that the spot where the two snaps join at your shoulder is protected by specially designed padding. We're always looking out for your comfort.

